

Aluminum Size Chart for 90° Elbow Covers

Iron Pipe Size	Insulation Thickness							
	½" No.	1" No.	1 ½" No.	2" No.	2 ½" No.	3" No.	3 ½" No.	4" No.
½"	#1	#2	#5	#8	#12	#23	#15	#25
¾"	#1	#2	#5	#8	#12	#23	#15	#25
1"		#3	#6	#11	#12	#23	#15	#25
1 ¼"		#3	#9	#11	#18	#23	#15	#25
1 ½"		#4	#9	#18	#23	#24	#25	#26
2"		#7	#10	#18	#20	#24	#25	#26
2 ½"		#13	#16	#20	#24	#30	#26	#31
3"		#14	#19	#22	#24	#30	#26	#31
3 ½"		#17	#21	#27	#30	#33	#31	#34
4"		#17	#21	#27	#30	#33	#31	#34
4 ½"		#28	#27	#30	#33	#39	#34	#40
5"		#28	#29	#36	#38	#39	#34	#40
6"		#32	#35	#37	#39	#44	#45	#57
7"		#35	#37	#39	#44	#45	#57	#52
8"		#41	#42	#43	#47	#49	#52	#53
9"		#42	#43	#47	#49	#52	#53	GORE
10"		#46	#50	#51	#55	#56	Q1	GORE
11"		#50	#51	#55	#56	Q1	Q3	GORE
12"		#48	#55	#56	Q1	Q3	Q5	GORE
14"		GORE	GORE	Q1	Q3	Q5	Q7	GORE
15"		GORE	GORE	GORE	Q5	Q7	Q9	GORE
16"		GORE	GORE	Q5	Q7	Q9	GORE	GORE
17"		GORE	GORE	GORE	Q9	GORE	GORE	GORE
18"		GORE	GORE	Q9	GORE	GORE	GORE	GORE

To Convert Inches to millimeters: Multiply Inches x 25.4 (Example: 1" x 25.4 = 25.4mm)

